

SALVATIONIST RESOURCES

Men's Uniform Measurement Chart

PLEASE READ INSTRUCTIONS ON REVERSE CAREFULLY



202 Cuba St (PO Box 6015, Marion Square, Wgtn 6141) | EMAIL mailorder@nzf.salvationarmy.org | PH (04) 382 0740 | FAX (04) 382 0722

Revised: August 2011

Name
Address
Phone

Date

Tick appropriate boxes

Trim/Style: Officer Soldier

Extra requirements


Measurements (refer to instructions first)

Chest (A)	cm
Waist (B)	cm
Seat (C)	cm
Outleg (D-E)	cm
Inleg (F-G)	cm
Shoulder width (H-I)	cm
Half cross back (J-K)	cm
Sleeve length (L)	cm
Neck to waist (M-N)	cm
Full length (M-O)	cm

Do you have:

Square shoulders:	<input type="radio"/>
Sloped shoulders:	<input type="radio"/>
Normal shoulders:	<input type="radio"/>
Short neck:	<input type="radio"/>
Long neck:	<input type="radio"/>

State any figure irregularity



Notes & Measuring Instructions for Men's Uniform

- This chart is for your made-to-measure formal lapel-style uniform suit (jacket and pants). Please note that shelf stock will cease to be available.
- Be very careful when taking your measurements! It's advisable that an experienced person takes your measurements. You may even want to get a local tailor to do this.
- Use a metric tape measure and always quote the nearest half cm.
- Wear the thickest clothing you'll want under your jacket. When taking measurements, hold the tape flat against the body, snug enough so that it doesn't droop but not so tight it feels restrictive.
- The tailor cannot take responsibility for errors in measurements you have taken, and correcting errors you made will incur extra costs for you. So please double check that the measurements you supply are correct.
- Allow an average of three weeks from the time we receive your instructions to delivery

To measure 'Chest' (A): Pass tape around greatest area of chest circumference. The tape should nestle as high as possible into the armpit. Check that the tape does not slide down the shoulder blades. Take measurement with finger between body and tape.

To measure 'Waistline' (B): Pass tape around smallest part of the waistline. Make sure you are relaxed. Take a relatively firm measurement.

To measure 'Seatline' (C): Take measurement over trousers. Pass tape around the greatest area of seat circumference.

To measure 'Outleg' (D-E): Ensure that trouser is sitting at desired position on waistline. Place end of tape at top of trouser band (D) and measure down the side seam of the trouser to (E). Ensure that the trousers being measured are of adequate length—point E should measure to approximately 3cm below the top of the shoe.

To measure 'Inleg' (F-G): Ensure the trouser is comfortable in the crotch area. Place end of tape at the top intersection between crotch and inleg seams, and measure inleg seam to position G (approximately 3cm below top of shoe).

All remaining measurements should be taken while wearing similar clothing to what you will wear under your jacket:

To measure 'Shoulder width' (H-I): Place tape on neck seam (H), lift collar and measure shoulder seam width to armhole seam (I).

To measure 'Half cross back' (J-K): Measure about 15cm from the neck seam to centre back, and mark with a pin (K). Place the end of tape on armhole seam (J) and measure across to pin (K).

To measure 'Sleeve length' (I-L): Place end of tape at top of shoulder seam (I) and measure straight down the sleeve to wrist position (L).

To measure 'Neck to waist' (M-N) and 'Full length' (M-O): Lift collar and place end of tape at centre back neck seam (M). Measure down to waist position (N). Hold the tape at this point and measure the desired full length position (O).

